

# RFA-4080: Serrated Jaws Pliers Kit

## CONTENTS

### RFA-4080-1 Side Cutter

4.25" (108mm) Oblique head for full flash cut. For copper wire only.

### RFA-4080-2 Round Nose

4.5" (114mm) Use to form wire loops on components.

### RFA-4080-3 Bent Nose

5" (127mm) Offset jaws for adjusting components in confined spaces.

### RFA-4080-4 Flat Long Nose


5" (127mm) For bending contact and relay springs, straightening or adjusting IC pins.

### RFA-4080-5 Half Round, Long Nose

5.125" (130mm) Use wherever you now use long nose pliers.

### RFA-4084 Gripper Nipper™ Side Cutter

4.25" (108mm) Specially equipped wire cutter holds the cut end until you release it. Prevents flying pieces of wire.



RF Connectors, Division of RF Industries, 7610 Miramar Road, San Diego, CA 92126-4202;

Toll Free: (800) 233-1728 Phone: (858) 549-6340; Fax: (858) 549-6345; Email: rfi@rfindustries.com; Web: www.rfindustries.com

# RFA-4081: Smooth Jaws Pliers Kit

## CONTENTS

### RFA-4081-1 Side Cutter

4.25" (108mm) Oblique head for full flash cut. For copper wire only.

### RFA-4081-2 Round Nose

4.5" (114mm) Use to form wire loops on components.

### RFA-4081-3 Bent Nose

5" (127mm) Offset jaws for adjusting components in confined spaces.

### RFA-4081-4 Flat Long Nose


5" (127mm) For bending contact and relay springs, straightening or adjusting IC pins.

### RFA-4081-5 Half Round, Long Nose

5.125" (130mm) Use wherever you now use long nose pliers.

### RFA-4084 Gripper Nipper™ Side Cutter

4.25" (108mm) Specially equipped wire cutter holds the cut end until you release it. Prevents flying pieces of wire.



RF Connectors, Division of RF Industries, 7610 Miramar Road, San Diego, CA 92126-4202;

Toll Free: (800) 233-1728 Phone: (858) 549-6340; Fax: (858) 549-6345; Email: rfi@rfindustries.com; Web: www.rfindustries.com